

<p>E054 SHOCK BODY &amp; PARTS SET (4)</p>	<p>E055 Front Shock Spring D=0.9 (2) ORANGE</p>	<p>E056 Rear Shock Spring D=0.9 (2) ORANGE</p>	<p>E057 Front Shock Spring D=1.0 (2) PURPLE</p>	<p>E058 Rear Shock Spring D=1.0(2) PURPLE</p>	<p>E059 Front Shock Spring D=1.1 (2) BLUE</p>	<p>E060 Rear Shock Spring D=1.1(2) BLUE</p>	<p>E061 Front Shock Spring D=1.2 (2) GREEN</p>
<p>E062 Rear Shock Spring D=1.2(2) GREEN</p>	<p>E063 BEARING 3x6x2.5 (6)</p>	<p>E064 BEARING 8x14x4 (2)</p>	<p>E065 BEARING 8x12x3.5 (6)</p>	<p>E070 BODY CLIPS (8)</p>	<p>NMT01 MAIN CHASSIS</p>	<p>NMT02 FRONT UPPER BRACE</p>	<p>NMT03 SPUR GEAR 50T</p>
<p>NMT04 BRAKE ADAPTER (2)</p>	<p>NMT05 CENTER BULKHEAD (2)</p>	<p>NMT06 CENTER UPPER PLATE</p>	<p>NMT07 BATTERY &amp; RECEIVER BOX</p>	<p>NMT10 FUEL TANK 40CC</p>	<p>NMT11 BRAKE CAM</p>	<p>NMT12 BRAKE PAD (2)</p>	<p>NMT13 CENTER DOGBONE REAR</p>
<p>NMT14 CENTER DOGBONE FRONT</p>	<p>NMT15 SERVO SAVER BOTTOM POST</p>	<p>NMT16 CLUTCH BELL 15T</p>	<p>NMT17 FLYWHEEL NUT</p>	<p>NMT18 FLYWHEEL</p>	<p>NMT19 BRAKE DISK</p>	<p>NMT22 9G SERVO MOUNTS (2)</p>	<p>NMT23 SERVO HORN L TYPE</p>
<p>NMT24 SERVO HORN</p>	<p>NMT25 EXHAUST GASKET</p>	<p>NMT26 FLYWHEEL COLLET</p>	<p>NMT28 BRAKE LAVER</p>	<p>NMT29 CLUTCH SHOES W/SPRING</p>	<p>NMT30 MANIFOLD</p>	<p>NMT31 PIPE HOLD SET</p>	<p>NMT32 SILICONE JOINT</p>